

Summary	Installing a patch kit for damaged Turbo Slide panels				
Products Affected	Turbo Slide Doors				
Key Word Tags	Patch Kit, Turbo Slide				
Tools/Equipment (If Required)	Acetone or Denatured Alcohol, Clean Rag, Scissors or Utility Knife				
Parts/Materials (If Required)	PANEL PATCH,12 X 12,WHITE, COLD CHAIN		R1091237-0A		
	PANEL PATCH,12 X 12,BLUE, COLD CHAIN		R1091237-0B		
Related Media					
Author	Mike Burzlaff	Issue Date	9/27/2016	Status	Active

Please Read The Entire Bulletin Before Proceeding

The following procedure details the installation instructions for patching the Turbo Slide panels. The maximum size tear/hole that can be patched 11" x 11".



The disconnect must be in the OFF position and properly locked and tagged before performing the next step of the procedure.

Install process:

- 1) Clean the door area for the patch with acetone or denatured alcohol and let dry
- 2) If needed, trim the patch to the appropriate size.
- 3) Peel off the tape backing and apply the patch to cleaned area
- 4) Secure patch by pressing on with roughly 7 to 10psi of pressure (this can be achieved by pressing on and rubbing by hand).

If you have any questions please contact Rytec Customer Support at 1-800-628-1909.