

Summary	Acceptable Cleaning Agents for the Turbo Slide Panels				
Products Affected	Turbo Slide				
Key Word Tags	Panel, TSL, Cleaning				
Tools/Equipment (If Required)					
Parts/Materials (If Required)					
Related Media					
Author	M. Burzlaff	Issue Date	5/1/17	Status	Active

Please Read The Entire Bulletin Before Proceeding

Turbo-Slide Chemical Cleaning Agent Compatibility

<u>Chemical</u>	<u>Single Slide Door</u>	<u>Bi-Part Door</u>	<u>Remarks</u>
Alcohols: Isopropyl	OK	OK	
Borax	OK	OK	
Household Bleach	OK	OK	
Prosat alcohol saturated wipes 18889-002	OK	OK	
Prosat alcohol saturated wipes 89138-004	OK	OK	
Simple Green	OK	OK	
Sodium Bicarbonate	OK	OK	
Sodium Carbonate	OK	OK	
Sodium Hydroxide (20%)	OK	NO	Closed Cell Foam in Bi-Part Tongue & Groove Seal susceptible to Sodium Hydroxide (20%)
Sodium Hypochlorite (<20%) ("bleach")	OK	OK	

If you have any questions please contact Rytec Customer Support at 1-800-628-1909.